



Dimensions:

[inches]

NOTES:

1. PURCHASED ITEM INCLUDES CASE, RUBBER FEET AND SCREWS (FOR SECURING OPTIONAL CAMERA).
2. DETAILED ASSEMBLY INSTRUCTIONS AVAILABLE FOR CASE AND OPTIONAL CAMERA CARD.


MC-RP002

www.farnell.com

INSTALLING THE RASPBERRY PI B+ INTO THE MC-RP002 **ENCLOSURE**















STEP 1

TAKE THE BOTTOM PART OF THE **ENCLOSURE AND INSERT THE** DEVELOPMENT BOARD ON AN ANGLE AGAINST THE STATIONARY CLIPS.



PUSH DOWN FIRMLY ON THE HDMI PORT UNTIL YOU HEAR THE **BOARD CLICK IN** PLACE.




TAKE THE TOP PART OF THE **ENCLOSURE AND** LINE UP THE TWO CLIPS ON THE USB SIDE ON AN ANGLE.



STEP 4

TO SECURE **ENCLOSURE PUSH** DOWN ON THE **OUTER TOP EDGE** UNTIL YOU HEAR A

ON THE BOTTOM OF THE ENCLOSURE. PLACE RUBBER ADHESIVE FEET IN THE CIRCLES

























MC-RP002 ASSEMBLY

OPTION #1

AFTER THE PI BOARD HAS BEEN CONNECTED TO THE BOTTOM PORTION OF THE CASE, TAKE THE CAMERA AND RUN IT THROUGH THE TOP OF THE CASE CONNECTING IT TO THE PROPER





YOU CAN NOW CLOSE THE CASE, MAKING SURE THE CABLE AND CAMERA ARE CLEAR SO YOU DO NOT DAMAGE THEM WHEN CLOSING




TAKE THE CAMERA AND INSERT IT INTO THE SLOT SO THE CAMERA IS ORIENTATED AS SEEN IN THE PICTURE.





OPTION #2

YOU WILL NEED THE TOP OF THE CASE, YOUR PI CAMERA, TWO SUPPLIED **SELF-TAPPING SCREWS** #2X3/16" OR (M2X4.5mm) AND A #1 SCREW DRIVER.





PLACE THE CAMERA ON THE POSTS MAKING SURE THE CAMERA LENS SITS IN THE CUTOUT OF THE CASE.






INSTALL THE TWO SCREWS INTO THE OTHER TWO POSTS, SECURING THE CAMERA INTO PLACE.





CONNECT THE CAMERA CABLE TO THE PI





YOU CAN NOW CLOSE THE CASE, MAKING SURE **CLEAR SO YOU DO NOT**

